

Part#: wUASB64UN	Title: Department:	Closure Instruction for UASB64UN Product Management
----------------------------	-------------------------------------	--

IMPORTANT NOTE

This closure instruction includes the assembly procedures for this packaging design. Substitution of materials or a change to these closure instructions may cause non-compliance with regulations and void the test certification for the packaging.

Product Components

INCLUDED WITH THE PACKAGING

1 – Corrugated box (UASB64UN)

MAY NOT BE INCLUDED WITH THE PACKAGING

3M 372 tape

5/16" bubble type wrap

ASSEMBLY INSTRUCTIONS

1. Fold the bottom flaps to close the box. Be sure the Manufacturer's certification is on the outside of the box.
2. Tape the box closed along the seam. A minimum of 2" overlap is required on each side.
3. Wrap airbag module or article in bubble cushioning material. There must be 2" of cushioning between the module or article and the outside of the packaging.
4. Place the wrapped module or article in the box.
5. Fold the top flaps of the box toward each other to close the box.
6. Tape box closed along center seam. A minimum of 2" overlap is required on each side.

SHIPPERS RESPONSIBILITIES

This UN combination package is performance tested with one (1) article, 61-1/8" x 2-1/2" x 3-3/8" weighing 13.6 kg. If using a smaller module or article, cushioning material must be added to fill void spaces. If the packaging is compatible with and authorized for your materials, then follow the instructions for proper closure. Consult 49 CFR 178.601(g)(1) for the rules on inner packaging and other applicable regulations.