

SOFTWARE PRODUCTS SERVICES

Part# <u>Title:</u> Closure Instruction w1PABSGM <u>Department:</u> Product Management

IMPORTANT NOTE

This closure instruction includes the assembly procedures for this packaging design. Substitution of materials or a change to these closure instructions may cause non-compliance with regulations and void the test certification for the packaging.

Product Components

INCLUDED WITH THE PACKAGING

1 - Corrugated Box (BOX1PABSGM)

MAY NOT BE INCLUDED WITH THE PACKAGING

3M 375 TAPE

12" x 12" Bubble Wrap Sheets (3/4")

ASSEMBLY INSTRUCTIONS

- 1. Fold the flaps at the bottom of the box so that the manufacturer's certificate appears on the outside of the
- 2. Tape the flaps closed. A minimum of 2" overlap is required on each side.
- 3. When using 3/4" Bubble Wrap Wrap airbag module in bubble cushioning material at least once and place the wrapped module in the box.
- 4. Fold the top flaps of the box toward each other to close the box.
- 5. Tape box closed along center seam. A minimum of 2" overlap is required on each side.

SHIPPERS RESPONSIBILITIES

This UN combination package is performance tested for use with 1 article such as an airbag module shipper, equipment part or battery. Cushioning material must be added to fill void spaces, if any. If the packaging is compatible with and authorized for your materials, then follow the instructions for proper closure. Consult 49 CFR 178.601(g)(1) for the rules on inner packaging and other applicable regulations.