

<b>Part#</b> w1PABLGM	<b>Title:</b> <b>Department:</b>	<b>Closure Instruction</b> <b>Product Management</b>
--------------------------	-------------------------------------	---

**IMPORTANT NOTE**

This closure instruction includes the assembly procedures for this packaging design. Substitution of materials or a change to these closure instructions may cause non-compliance with regulations and void the test certification for the packaging.

**Product Components**

**INCLUDED WITH THE PACKAGING**

- 1 – Corrugated Box (BOX1PABLGM)

**MAY NOT BE INCLUDED WITH THE PACKAGING**

- 3M 375 TAPE
- 12" x 12" Bubble Wrap Sheets (3/4")
- 12" x 12" Bubble Wrap Sheets (3/16")

**ASSEMBLY INSTRUCTIONS**

1. Fold the flaps at the bottom of the box so that the manufacturer’s certificate appears on the outside of the box.
2. If using 3/4" Bubble Wrap – Wrap airbag module in bubble cushioning material at least once and place the wrapped module in the box.
3. If using 3/16" Bubble Wrap - Wrap airbag module in bubble cushioning material at least once and place the wrapped module in the box.
4. Fold the tuck-in flap and secure the locking tabs in place.
5. Tape box closed along the tuck-in flap from edge to edge. A minimum of 2" overlap is required on each side.

**SHIPPERS RESPONSIBILITIES**

This UN combination package is performance tested for use with 1 article such as an airbag module shipper, equipment part or battery. Cushioning material must be added to fill void spaces, if any. If the packaging is compatible with and authorized for your materials, then follow the instructions for proper closure. Consult 49 CFR 178.601(g)(1) for the rules on inner packaging and other applicable regulations.